



Installation and Maintenance Manual

Floor Ceiling Air Conditioner	
R-410A 50Hz Heat Pump	R-410A 50Hz Cooling Only
Model:YFKN18BZNREUH1 YFKN24BZNREUH1 YFKN36BZNREUH1 YFKN42BZMREUH1 YFKN48BZMREUH1 YFKN55BZMREUH1	Model:YFJN18BZNRETH1 YFJN24BZNRETH1 YFJN36BZNRETH1 YFJN42BZMRETH1 YFJN48BZMRETH1 YFJN55BZMRETH1
Version: YPM2017010HC	

Alert Symbols.....	1
Caution Statements.....	2
Composition of the Air-Conditioner.....	3
Operation Manual	
Special Remarks.....	5
Trouble shooting.....	5
Diagram of Refrigerant Cycle & Wiring	
1.Refrigerant Flow Diagram.....	7
2.Electrical Wiring Diagram.....	7
Installation and Maintenance	
1.Safety Notice.....	8
2.The Tools and Instruments for Installation.....	9
3.The Installation of the Indoor Unit.....	9
3.1 Before Installation.....	9
3.2 Installation Location.....	11
3.3 Installation.....	11
4.Refrigerant Piping.....	14
4.1 The Piping Material.....	14
4.2 Piping Connection	14
5.Drain Piping.....	15
6.Electrical wiring.....	16
7.Attaching the Air Return Grille.....	16
8.The Installation of the Outdoor Unit	17
8.1 Installation Sites.....	17
8.2 Installation of the Outdoor Unit.....	17
9.Refrigerantpiping.....	18
9.1 Flaring with Tube Expander.....	18
9.2 Connecting piping Between Indoor and Outdoor Units	18
9.3 Heat Insulation of the Refrigerant Tube.....	18
9.4 Taping the Piping	18
9.5 Finishing the Installation.....	18
10.Air Purging and Test Run.....	18
10.1 Air Purging with a Vacuum Pump.....	18
10.2 Leak Test.....	19
10.3 Tidying Up the piping	19
10.4 Test Run.....	19
10.5 Electrical installation.....	20

NOTE

- This air conditioner has been designed for the following temperatures. Operate the air-conditioner within this range.

Series	Mode	Outdoor operating temperature range	
		Maximum(℃)	Minimum(℃)
Heat Pump	Cooling Operation	48	-15
	Heating Operation	24	-15
Cooling Only	Cooling Operation	48	-15

- Storage condition: Temperature -25~60℃
Humidity 30%~80%

Alert Symbols:

-  **DANGER** : The symbol refers to a hazard which can result in severe personal injury or death.
-  **WARNING** : The symbol refers to a hazard or an unsafe practice which may result in severe personal injury or death.
-  **CAUTION** : The symbol refers to a hazard or an unsafe practice which may result in personal injury, product or property damage.
It refers to the remarks and instruction to the operation, maintenance, and service.

Caution Statements

- We recommend that this air-conditioner is installed properly by qualified installation technicians in accordance with the installation instructions provided with the unit.
- Before installation, check if the voltage of the power supply at installation site is the same as the voltage shown on the nameplate.

DANGER

- You must not carry on any transformation to this product, otherwise, it may possibly cause such consequences as water leakage, breakdown, short-circuit, electric shock, fire, etc.
- The work such as piping welding, etc. should be carried out far away from flammable explosive material vessels, including the air-conditioner refrigerant, to guarantee the security of the site.
- To protect the air-conditioner from heavy corrosion, avoid installing the outdoor unit where salty seawater can splash directly onto it or in sulphurous air near a spa. Do not install the air-conditioner where excessively high heat-generating objects are placed.

WARNING

- If the supply cord is damaged, it must be replaced by the factory or its service department in case of danger.
- The place where this product is installed must have the reliable electrical earth facility and protections. Please do not connect the grounding of this product to various kinds of air-feeding ducts, drain piping, lightning protection facility as well as other piping lines to avoid receiving an electric shock and damages caused by other factors.
- Wiring must be done by a qualified electrician. All the wiring must comply with the local electrical codes.
- Consider the capacity of the electric current of your electrical meter and socket before installation.
- The power wire where this product is installed is supposed to have the independent leakage protective device and the electric current over-load protection device which are provided for this product.
- The appliance is not to be used by persons who lack of experience and knowledge, unless they have been given supervision or instruction. Children should be supervised not to play with the appliance.
- Means for disconnection, which can provide full disconnection in all poles, must be incorporated in the fixed wiring in accordance with the wiring rules.

- **Read this manual carefully before using this air-conditioner. If you still have any difficulties or problems, consult your dealer for help.**
- **The air-conditioner is designed to provide you with comfortable room conditions. Use this unit only for its intended purpose as described in this instruction manual.**

WARNING


- Never use gasoline or other inflammable gas near the air-conditioner, which is very dangerous.
- When the air conditioner operation is abnormal, such as burnt smell, deformation, fire, smoke, etc., it is forbidden to continue using the air conditioner, the main power switch of the air conditioner must be cut off immediately and the agent must be contacted.

CAUTION


- Do not turn the air-conditioner on and off from the power main switch. Use the ON/OFF operation button.
- Do not stick anything into the air inlet and air outlet of both the indoor and outdoor units. This is dangerous because the fan is rotating at a high speed.

Composition of the Air-conditioner


Indoor Unit



Outdoor Unit



18K,24K,36K,42K



48K,55K

Notes:

Figures in the manual are only simple representation of the appliance, it may not comply with the appearance of the air conditioner you have purchased.

Vertical adjustment louver swing automatically function is only available for some models.

Composition of the Air-conditioner

Wire remote controller (optional)

You can control the air-conditioner with the wired remote controller or wireless remote controller. It is used for power ON/OFF, setting the operating mode, temperature, fan speed and other functions. There are different types of remote controllers which can be used. Operation instruction will be further specified in remote controller's manual separately. Please read it carefully before using this appliance and keep it for future reference.

Wired remote controller




JCSA21NEWH

Wireless remote controller



JCRA31NEWH

Display Panel



- The figures in this manual are based on the external view of a standard model. Consequently, the shape may differ from that of the air conditioner you have selected.
- * It can be set or canceled by professional after-sale staff.

Special remarks

- **3 minutes protection after compressor stop**
To protect compressor, it will be continue off for at lest 3 minutes once it has stopped.
- **5 minutes protection**
Compressor must run 5 minutes at least once start running. In the 5 minutes, compressor will not stop even the room temperature reaches the set point unless you use remote control switch to turn off the unit (all indoor unit can be turned off by user).
- **Cooling operation**
The fan of the indoor unit will never stop running in cooling operation. It remains running even if the compressor stops working.
- **Heating operation**
Heating capacity depends on external factors as outdoor unit temperature. Heating capacity might decrease if outdoor ambient temperature is too low.
- **Anti-freezing function during cooling**
When the temperature of the air from the indoor outlet is too low, the unit will run for some time under the fan mode, to avoid frost or ice forming in the indoor heat exchanger.
- **Cold air prevention**
In several minutes after the heating mode is started, the fan of the indoor unit will not run until the heat exchanger of the indoor unit reaches a certain temperature in order to prevent cold draft.
- **Defrosting**
When the outdoor temperature is too low, frost or ice may form in the outdoor heat exchanger, reducing heating performance. When this happens, a defrosting system of the air conditioner will operate. At the same time the fan in the indoor unit stops(or runs at a very low speed in some cases), to prevent cold draft. After defrosting is over, the heating operation and fan speed restart.
- **Blowing out the residual heating air**
When stoping the air conditioner in normal operation, the fan motor would run with low speed for a while to blow out the residual heating air.
- **Auto re-start from Power Break**
When the power supply is recovered after power break, all preset are still effective and the air-conditioner will run according to the previous setting.

Troubleshooting



if overflow of drain water from the indoor unit occurs, stop the operation and contact your contractor.

if you smell or see white smoke coming from the unit, turn OFF the main power supply and contact your installer.

1.If Trouble Still Remains ...

If the trouble still remains even after checking the following, contact your installer and inform them of the following items.

- (1)Unit Model Name
- (2)Content of Trouble

2.No Operation

Check whether the SET TEMP is set at the correct temperature.

3. Not Cooling or Heating properly

- Check for obstruction of air flow at outdoor or indoor units.
- Check if too many heating sources are located in the room.
- Check if the air filter is clogged with dust.
- Check if the doors or windows are open.
- Check if the temperature condition is not within the operation range.

4. This is Not Abnormal

- **Smells from indoor unit**
Smell adheres on indoor unit after a long period of time. Clean the air filter and panels or allow a good ventilation.
- **Sound from Deforming Parts**
During system starting or stopping, a sound might be heard. However, this is due to thermal deformation of plastic parts. It is not abnormal.
- **Steam from Outdoor Heat Exchanger**
During defrosting operation, ice on the outdoor heat exchanger is melted, resulting in making steam.
- **Dew on Air Panel**
When the cooling operation continues for a long period of time under high humidity conditions (higher than 27°C / 80%R.H.), dew can form on the air panel.
- **Refrigerant Flow Sound**
While the system is being started or stopped, sound from the refrigerant flow may be heard.

5. Filter removing and installing

● Removing filter from air return grille


Take out the air filter according the following steps.

Step1

Slide the air return grille holding knobs(4) , then remove the holding screws(4 or 6) as indicated by the arrow marks.

Step2

Open the air return grille to an angle of more than 45° and take out the air filter from the air inlet grille by holding the air grille and lifting the air filter after detaching the filter from the hinges.




● Installing the filter


Step1: Insert the filter to the grille and aim the bottom hooks. Pay attention to grille top hooks is locked.

Step2: Fix screws (4 or 6).


Step3: The intake grille is attached.




1. REFRIGERANT FLOW DIAGRAM



2. ELECTRICAL WIRING DIAGRAM



18K/24K/36K



42K/48K/55K

1.Safety Notice

WARNING

- Installation should be performed by a professional. (Improper installation may cause water leakage, electrical shock or fire).
- Install the unit according to the instruction given in this manual. (Incomplete installation may cause water leakage, electrical shock or fire).
- Be sure to use the supplied or specified installation parts. (Use of other parts may cause the unit to come to lose, water leakage, electrical shock or fire).
- Install the air conditioner on a solid base that can support the unit weight. (An inadequate base or incomplete installation may cause injury in the event the unit falls off the base).
- Electrical work should be carried out in accordance with the installation manual and the local national electrical wiring rules or code of practice.
(Insufficient capacity or incomplete electrical work may cause electrical shock or fire).
- Be sure to use a dedicated power circuit. (Never use a power supply shared by another appliance).
- For wiring, use a cable long enough to cover the entire distance Do not use an extension cord.
- Do not put other loads on the power supply, use a dedicated power circuit. (Failure to do so may cause abnormal heat, electric shock or fire).
- Use the specified types of wires for electrical connections between the indoor and outdoor units. (Firmly clamp the interconnecting wires so their terminals receive no external stress).
- Incomplete connections or clamping may cause terminal overheating or fire.
- After connecting interconnecting and supply wiring be sure to shape the cables so that they do not put undue force on the electrical covers or panels. (Install covers over the wires, incomplete cover installation may cause terminal overheating, electrical shock or fire).
- When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air. (Any presence of air or other foreign substance in the refrigerant circuit causes an abnormal pressure rise or rupture, resulting in injury).
- If any refrigerant has leaked out during the installation work, ventilate the room. (The refrigerant produces a toxic gas if exposed to flames).
- After all installation is completed, check to make sure that no refrigerant is leaking out. (The refrigerant produces a toxic gas if exposed to flames).
- When carrying out piping connection, take care not to let air substances other than the specified refrigerant go into refrigeration cycle. (Otherwise, it will cause lower capacity, abnormal high pressure in the refrigeration cycle, explosion and injury).
- Make sure the installation has a proper earth connection. Do not earth the unit to a utility pipe, arrester, or telephone earth. Incomplete earth may cause electrical shock. (A high surge current from lightning or other sources may cause damage to the air conditioner).
- An earth leakage circuit breaker may be required depending on site condition to prevent electrical shock. (Failure to do so may cause electrical shock).
- Disconnect the power supply before completion of wiring, piping, or checking the unit.
- When moving the indoor unit and outdoor unit , please be careful,do not make the outdoor unit incline over 45 degree. Pay attention to the sharp edge of the air conditioner to avoid any injury.
- Installing the remote controller: Be sure that the length of the wire between the indoor unit and remote controller is within 40 meters.

CAUTION

- Do not install the air conditioner in a place where there is danger of exposure to inflammable gas leakage. (If the gas leaks and builds up around the unit, it may catch fire).
- Establish drain piping according to the instructions of this manual. (Inadequate piping may cause flooding).
- Tighten the flare nut according to the specified method such as with a torque wrench. (If the flare nut is tightened too hard, the flare nut may crack after a long time and cause refrigerant leakage).

2.The Tools and Instruments for Installation

Number	Tool	Number	Tool
1	Standard screwdriver	8	Knife or wire stripper
2	Vacuum pump	9	Gradienter
3	Charge hose	10	Hammer
4	Pipe bender	11	Churn drill
5	Adjustable wrench	12	Tube expander
6	Pipe cutter	13	Inner hexagon spanner
7	Cross head screw-driver	14	Tape measure

3.The Installation of the Indoor Unit





During installation, do not damage the insulation material on the surface of the indoor unit.

3.1 Before installation

- When moving the unit during or after unpacking, make sure to lift it by holding its lifting lugs.
Do not exert any pressure on other parts, especially the refrigerant piping, drain piping and flange parts.
- Wear protective gears when installing the unit.
- Install correctly according to the installation manual.
- Confirm the following points:
 - Unit type/Power supply specification
 - Pipes/Wires/Small parts
 - Accessory items

ACCESSORY ITEMS

Accessory		Q'ty	Purpose
Washer (M10)		8	For Unit Hanging
Paper Pattern		1	For Unit Hanging And Adjustment
Insulation		1	For Refrigerant Piping Connection
Insulation		1	
Cord Clamp		10	For Pipe Cover Fixing
Drain Hose		1	For Drain Pipe Connection
Hose Clamp		2	For Joint Socket Connection
HeavyInsulation		2	For Drain Hose Cover
Joint Socket		1	For Drain Hose Connection
Jump Ring		1	For Drain Hose Connection
Plastic Sheath		1	For Drain Hose And Piping Connection



3.2 Installation location

- Select the suitable areas to install the unit under approval of the user.
- The air path is not blocked.
- Condensate can drain properly.
- The ceiling is strong enough to bear the weight of the indoor unit.
- Sufficient clearance for maintenance and servicing is ensured.(See Fig.3.2.1)
 - Piping between the indoor and outdoor units is within the allowable limits.(refer to the installation of the outdoor unit)
 - The indoor unit, outdoor unit, power supply wiring and transmission wiring is at least 1 meter away from televisions and radio, to prevents interference and noise in those electrical appliances. (Noise may be generated depending on the conditions under which the electric wave is generated, even if a one-meter allowance is maintained.)
 - Use suspension bolts to install the unit, check whether or not the ceiling is strong enough to support the weight of the unit. If there is a risk that the ceiling is not strong enough, reinforce the ceiling before installing the unit.
 - If there are 2 units of wireless type, keep them away for more than 6 m to avoid malfunction due to cross communication.
 - When several indoor units are installed nearby, keep them away for more than 4-5m.

Space for installation and service




Fig. 3.2.1

3.3 Installation

According to the actual installation space, install it in the ceiling done at in the ceiling or on the floor.

3.3.1 Suspension bolts

(1) Consider the pipe direction, wiring and maintenance access carefully, and choose the proper direction and location for installation.

(2) Install the suspension bolts as shown in Fig. 3.3.1 below.





Fig. 3.3.1 Fixing the suspension bolts

3.3.2 The position of the suspension bolts and the pipes

(1) Mark the positions of the suspension bolts, the positions of the refrigerant pipes and the drain pipes.

(2) The dimension are shown below.



Capacity(Btu/h)	A	B
18K,24K	990	912
36K	1285	1207
42K,48K,55K	1580	1502

Fig. 3.3.2 Suspension bolts

※The outlet through which the pipings are taken out is available in three directions.

※Pipes can be taken out in 3 directions(rear, right or top).(See fig.3.3.3)

Cut out holes using nippers, etc.

Cut out holes to taken out pipes along the cutoff line on the rear cover.

Cut out the top face cover aligning to the piping position.

When taking pipe out to right-hand side, cut out a hole along the groove at the inside of the side panel.

After installing pipes and wires,seal clearances around pipes and wires with putty,etc. to shut off dust.

Make sure to install the covers at rear and top in order to protect the inside of unit from intrusion of dust or protect wires from damages by sharp edges. When taking them out to the right-hand side, remove burrs or sharp edges from the cutout.

(2) Remove side panel.

Remove the screw and detach the side panel by sliding it toward the direction indicated by the arrow mark.




Fig. 3.3.5

(3) Remove the hanging plate.

Remove the screw and then fixing bolts.




Fig. 3.3.6 Suspension bolts and nuts




Fig. 3.3.3

3.3.3Indoor unit preparation

(1)Remove the air return grille.

Slide stoppers (4 places) of the catches, then remove the screws(4 or 6 places).




Fig. 3.3.4

3.3.4Install the indoor unit **Ceiling type installation**

(1)Select the suspension bolt locations and the pipe hole location.

i.Use enclosed paper pattern as a reference, and drill the holes for the suspension bolts and pipe.

Note:Decide the locations based on the direct measurements.

ii.Once the locations are properly placed, the paper pattern can be removed.

2)Install the suspension bolts in place.




Fig. 3.3.7

Installation and Maintenance

(2)

- Place the left hanger bracket on the nuts and washers of the suspension bolts.
- Make sure that the left hanger bracket has been fixed on the nuts and washers securely, install the right hanger bracket suspension hook on the nuts and washers.

(When installing the indoor unit, you can slightly remove the suspension bolts.)




Fig. 3.3.8

(3) Fix with 4 suspension bolts, which can endure load of 530N.

(4) Check the measurements of the length of the suspension bolts.

(5) Fasten the hanging plate onto the suspension bolts.

(6) Install the unit to the hanging plate.

i. Slide the unit from front side to get it hanged on the hanging plate with bolts.

ii. Fasten the four fixing bolts (M8:2 each on the left and right sides) firmly.

iii. Fasten the two screws (M5:1 each on the left and right sides).




Fig. 3.3.9

Floor standing type installation

(1) Select the suspension bolt locations and the pipe hole location.

i. Use enclosed paper pattern as a reference, and drill the holes for the suspension bolts and pipe.

Note:

Decide the locations based on the direct measurements.

ii. After the locations are properly placed, the paper pattern can be removed.

(2) Install the suspension bolts in place.




Fig. 3.3.10

(3) Fix with 4 suspension bolts, and fasten the four fixing bolts (M8:2 each on the left and right sides) firmly.

(4) Fasten the two screws of Air Intake Grille (M5:1 each on the left and right sides).

3.3.5 The horizontal adjustment of the indoor unit

(1) Make sure that the hanger bracket is fixed by the nut and the washer.

(2) Adjust the height of the unit.

(3) Check if the unit is positioned horizontally.

*To ensure smooth drain flow, install the unit with a descending slope (0-3mm) toward the drain outlet.

(4) After the adjustment, tighten the nut and smear the thread locker on the suspension to prevent the nuts from loosening.



During the installation, please cover the unit with the plastic cloth to keep it clean.

4.Refrigerant Pipe

⚠ DANGER

Use the R410A refrigerant. When carrying on the leakage check and test, do not mix in the oxygen, the acetylene and flammable and the reactive gas, these gases are quite dangerous, and may possibly cause explosion. It is suggested that the compressed air, the nitrogen or the refrigerant is used to perform these experiments.

4.1 The Pipe Material

- (1) Prepare the copper pipe on the spot.
- (2) Choose dustless, non-humid, clean copper pipe. Before installing the pipe, use nitrogen or dry air to blow away the tube dust and impurity.
- (3) Choose the copper pipe according to Fig. 4.2.

4.2 Piping connection

- (1) The connection positions of the pipe are shown in Fig. 4.1 and Fig. 4.2.





Fig. 4.1 The connection positions of the tube

Capacity (Btu/h)	Gas pipe	Liquid pipe	Drain pipe
18K	φ 12.7	φ 6.35	De25
24K	φ 15.88	φ 9.52	De25
36K,42K,48K,55K	φ 19.05	φ 9.52	De25


Fig. 4.2 The pipe diameter

The pipe can be connected from three different directions.(rear, right, top).
When the pipe is routed through the back.
If the bracket is removed, piping work will become easier.
After piping, reinstall the removed bracket.



When the pipe is routed through the back.
Cut the removed top cover, and install to the rear panel instead of rear cover.

- (2) As shown in Fig. 4.3, screw up the nuts with 2 spanners.



Tube size	Torque (N·m)
φ 6.35mm	20
φ 9.52mm	40
φ 12.7mm	60
φ 15.88mm	80
φ 19.05mm	100

Fig. 4.3 Screw up the nut torque

- (3) After finishing connecting the refrigerant pipes, keep it warm with the insulation material.





Fig. 4.4 Piping insulation procedure


⚠ CAUTION

- The pipe go through the hole with the seal.
- Do not put the pipes on the floor directly.



5. Drain piping

- Install the drain piping



- Make sure the drain works properly.
- The diameter of drain pipe connection hole should be same as that of the drain pipe.
- Keep the drain pipe short and sloping down wards at a gradient of at least 1/100 to prevent air pockets from forming.




CAUTION

Water accumulating in the drain piping can cause the drain to clog.

To keep the drain tube from sagging, space hanging wires every 1 to 1.5 m.

- Use the drain hose and the clamp. Insert the drain hose fully into the drain socket and firmly tighten the drain hose and warm-keeping material with the clamp.
- The two areas below should be insulated because condensation may form there causing water to leak.
- Drain piping passing indoors
- Drain sockets.
- Referring the figure below, insulate the drain socket and drain hose using the included large sealing pad.



CAUTION


Drain piping connections

- Do not connect the drain directly to sewage pipes that smell of ammonia. The ammonia in the sewage might enter the indoor unit through the drain pipes and corrode the heat exchanger.

- Do not twist or bend the drain hose, so that excessive force is not applied to it.

This type of treatment may cause leaking.

- After piping work is finished, check drainage flows smoothly.
- Gradually insert approximately 1000 cc of water into the drain pan to check drainage in the manner described below.
- Gradually pour approximately 1000 cc of water from the outlet hole into the drain pan to check drainage.
- Check the drainage.



6. Electrical wiring

⚠ CAUTION


- When clamping the wiring, use the included clamping material as shown in the FIG.6.1 to prevent outside pressure being exerted on the wiring connections and clamp firmly.
- When doing the wiring, make sure the wiring is neat and does not cause the control box lid to stick up, then close the cover firmly. When attaching the control lid, make sure you do not pinch any wires.
- Outside the machine, separate the weak wiring(remote controller and transmission wiring) and strong wiring (earth and power supply wiring) at least 50 mm so that they do not pass through the same place together. Proximity may cause electrical interference. Malfunction, and breakage.

⚠ WARNING

- If the fuses burn up, please call the service agency. Please do not replace by yourself, as may result in accident, for example shock.
- (1) Remove the screws on the control box.
 - (2) Connect the power cord and earth wire to the main terminal.
 - (3) The remote control wire to the subsidiary terminal box according to electric wiring diagram.
 - (4) Connect the power supply of the indoor and outdoor units to the main terminal.
 - (5) Tie the wire in the control box with the clamp tightly.
 - (6) After finishing the wiring, seal the wiring hole with the sealing material (with the lid) to prevent the condensed water and insects entering.

7. Attaching the air return grille

- The air return grille must be attached when electric cabling work is completed.
- (1) Fix the air return grille onto the indoor unit with screws supplied as accessories(4 pieces).
 - (2) Close the air return grille.
- This completes the unit installation work.



8.The Installation of the Outdoor Unit

8.1 Installation sites

Avoid

- Direct sunlight
- Thick Oil fog
- Container With Flammable materials
- Near Heat Source/ventilation fan
- Aisle Or sideways
- Wet Or Uneven place

You should

- Place it in cool temperature.
- Place it in an area with good ventilation.
- Have required space for air inlet, outlet and maintenance. (Figure 8.1)
- Make a strong base(10X40cm² board made of concrete or similar). The appliance should be placed not less than 10 cm high to avoid being wet or corroded. Otherwise, it may cause damage to the appliance or reduce its life time. (Figure 8.2)
- Fix the base with hook bolts or alike to reduce vibration and noise.

If the total tube length is between 5m and 50m (Max. length), an additional refrigerant must be added. It's not necessary to add compressor oil. (Figure 8.3)




Fig. 8.1




Fig.8.2




Fig.8.3

8.2 Installation of the outdoor unit

Firstly select the installation site and fix the outdoor unit. If it needs to be fixed onto the wall, make sure that the wall and the supporting rack is strong enough to hold the weight of the appliance.

Wiring instruction for outdoor unit

- Release the setscrews of the electric cover, remove the electric cover (If the valve cover is there either, please release it).
- Connect the indoor unit wiring to the outdoor unit panel according to the electric wiring diagrams.
- Be sure to make each wire allowing 10cm longer than the required length for wiring.
- Ground the unit following local electrical regulations.
- Check the wiring with the wiring diagrams and make sure it's well connected. Fix the wiring with clips and reinstall the electric cover.

- Fix the unit with wire ropes to prevent overturning in case a seasonal strong wind (storm, etc.) blows against the unit.




Fig.8.4

9. Refrigerant piping

9.1 Flaring with Tube Expander

Note: A good flare have the following characteristics:

- Inside surface is glossy and smooth.
- Edge is smooth.
- Tapered sides are of uniform length.

- Remove the burrs at the end of the copper tube with a tube reamer or file. When reaming, hold the tube bend downward and be sure that no copper scraps fall into the tube. This process is important and should be done carefully to make a good flare. (Figure 9.1, 9.2)
- Remove the flare nut from the unit and be sure to mount it on the copper tube.
- Make a flare at the end of copper tube with a flare tool. (Figure 9.3)

- The two refrigerant tubes (and electrical wire if local codes permit) should be taped together with white armoring tape. The drain hose may also be included and taped together as a bundle with the piping.
- Wrap the tape from the bottom of the outdoor unit to the top of the piping where it enters the wall. As you wrap the piping, overlap half of each previous tape. (See Figure 9.7)
- Clamp the piping bundle to the wall, using one clamp approx. every 120 cm.

9.2 Connecting piping between Indoor and Outdoor Units

- Be sure to apply a sealing cap or water-proof tape to prevent dust or water from getting into the tubes before they are used.
- Be sure to apply refrigerant lubricant to the matching surfaces of the flare and union before connecting them together. This is effective for reducing gas leaks. (Figure 9.4)
- For proper connection, align the union tube and flare tube straight with each other, then tighten the flare nut lightly to obtain a smooth match. (Figure 9.5)
- Tighten the setscrew with torque wrench to prevent leak of refrigerant. Carefully test leak before running the appliance.

9.3 Heat Insulation of the Refrigerant Tube


To avoid loss of heat and in prevention of the ground being wet by condensed water, all refrigerant tubes must be insulated with suitable insulating materials whose minimum thickness will be 6 mm. (See Figure 9.6)

9.4 Taping the Tubes

Note: Do not bind the armoring tape too tightly because this will decrease the heat insulation effect. Also be sure the condensed drain hose splits away from bundle and drips clear of the unit and the piping

9.5 Finishing the installation

After completion of wrapping and insulation, seal the hole on the wall with suitable seal against wind and rain.



10. Air purging and test run

Air and moisture remaining in the refrigerant system have undesirable effects.

Therefore, they must be purged completely following the steps.

10.1 Air Purging with a Vacuum Pump (See Figure 10.1, Figure 10.2)

- (1) Check that each pipe (both narrow and wide pipes between the indoor and outdoor units) have been properly connected and all wiring for the test run has been completed. Note that both narrow and wide pipes valves on the outdoor unit are kept closed at this stage.
- (2) Using an adjustable wrench or box wrench, remove the bonnet from the service valve.
- (3) Connect a vacuum pump and service valve together tightly.
- (4) Turn on the vacuum pump and till the pressure is lower than 15Pa (or 1.5×10^{-4} bar) for 5 minutes.
- (5) With the vacuum pump still running, disconnect pipe of vacuum pump from the service valve. Then stop the vacuum pump.
- (6) Replace the bonnet on the service valve and fasten it securely with an adjustable wrench or box wrench.
- (7) Using an adjustable wrench or box wrench, remove the bonnet of both narrow and wide valve.
- (8) With the hex wrench, turn the wide and narrow pipes valves stem counter clockwise to fully open the valves.
- (9) Replace the bonnets on the wide and narrow valves and fasten it securely with an adjustable wrench or box wrench.

10.2 Leak Test

- Leak test all joints and valves of the indoor unit and outdoor unit with liquid soap. Checking of the orifice cap shouldn't be less than 30 seconds. Clean the liquid soap after the test in case that the color of the copper tube may change for erode.

10.3 Tidy Up the piping

- If the leak test turns out to be all right, preserve heat the joints of the indoor unit.
- Straighten the connecting tubes and make them flush and fixed to the wall. Seal the space around the hole in the wall through which the pipes come out with gypsum.

10.4 Test Run

The trial should be carried out according to the installation and maintenance manual.

⚠ WARNING



• Only after all the checking points have been checked the unit can be operated.

(A) Check and make sure that the resistance of the terminal to ground is more than $2M\Omega$, otherwise, you cannot operate the unit before the electricity leakage point is found and repaired.

(B) Check and make sure that the stop valve has been opened before operating the unit.

- Make sure the power and unit run well then plug in.
- Turn on the appliance and adjust it to Cooling, dehumidifying and Heating mode according to the room temperature. Check if the appliance can run well.

Installation of the appliance is generally finished after the above operations are done. If you still have any trouble, please contact local technical service center of our company for further information.



10.5 Electrical installation



WARNING

- Use an ELB (Electric Leakage Breaker). If not used, it might cause an electric shock or a fire.
 - Do not operate the system until all the check points have been cleared.
- (A) Check to ensure that the insulation resistance is more than 2 MΩ , by measuring the resistance between ground and the terminal of the electrical parts. If not, do not operate the system until the electrical leakage is found and repaired.
- (B) Check to ensure that the stop valves of the outdoor unit are fully opened and then start the system.

Model Capacity(Btu/h)	Power Supply	ELB		Power Source Cable Size	Transmitting Cable Size
		Nominal Current(A)	Nominal Sensitive Current (mA)	En60 335-1	En60 335-1
18K	220-240V ~,50Hz	20	30	3×2. 5mm ²	4×1. 5mm ²
24K	220-240V ~,50Hz	32	30	3×2. 5mm ²	4×1. 5mm ²
36K	220-240V ~,50Hz	40	30	3×4. 0mm ²	4×1. 5mm ²
42K/48K/55K	380-415V 3N~,50Hz	32	30	5×2. 5mm ²	4×1. 5mm ²

Max. Running Current(A):REFER TO NAMEPLATE


NOTES:

- 1) Follow local codes and regulations when selecting field wires, and all the above are the minimum size.
- 2) The wire sizes marked in the table are selected at the maximum current of the unit according to the European Standard , EN60335-1. Use the wires which are not lighter than the ordinary polychloroprene sheathed flexible cord (code designation H07RN-F) .

When connecting the terminal block using flexible cord, make sure to use the round crimp-style terminal for connection to the power supply terminal block.

Place the round crimp-style terminals on the wires up to the covered part and secure in place.

When connecting the terminal block using a single core wire, be sure to perform curing.



- 3) When transmitting cable length is more than 15 meters, a larger wire size should be selected.
- 4) Use a shielded cable for the transmitting circuit and connect it to ground .
- 5) In the case that power cables are connected in series, add each unit maximum current and select wires below.

Selection According to EN60335-1

Current i(A)	Wire Size(mm ²)
i≤6	0. 75
6<i≤ 10	1
10<i≤ 16	1. 5
16<i≤ 25	2. 5
25<i≤ 32	4
32<i≤ 40	6
40<i≤ 63	10
63<i	*

*In the case that current exceeds 63A, do not connect cables in series.



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.